## **KMAX S 50 Standalone Access Control**

We offer the smart and safe way to enter your home.



## **Specification**

- The storage capacity of 2,000 user card and 2,000 user password.
- · Open three ways: card, password, card and
- · Ultra-low power consumption: standby current is less than 30 ma.
- · Independent password
- User can change and modified password code them self.
- Swipe to open the door of time is less than 0.1s
- Card type: EM (ID Card) IC card is optional







PROGRAMMING CODE 编程代码	[####] [123456] [#], DEFAULT = 123456 (默认)
CHANGE PROGRAMMING CODE 更改编程代码	[0] [NEW 6-DIGITS] [#] [REPEAT 6-DIGITS] [#] 新6位数字 重复6位数字
ADD USER CARD BY CONTINOUSLY 添加多个用户卡	[1] [SWIPE NEW CARD] [#], START FROM 0001~2000 刷新卡, 數字从 0001 开始至 2000
PROGRAM TIMER (IN SECOND) 设置时间(秒)	[5]+[XX]+[#], SET IN : 01~99
SET NEW USER PASSWORD 设置新用户密码	[6]+[XXXX]+[#]+[REPEAT:XXXX]+[#], EXAMPLE:1234#
DELETE USER CARD ONE BY ONE 逐张删除用户卡	[30]+[SWIPE CARD]+[#]
DELETE USER CARD BY NUMBER 按编号删除用户卡	[31]+[0001~2000]+[#]
DELETE ALL USER CARDS 删除所有用户卡	[32]+[9999]+[#]
EXIT SYSTEM 退出设置	[#]
RESET FACTORY DEFAULT 恢复出厂默认设置	TURN-OFF POWER, SWIPE [ ON ] DIP-SWITCH AND TURN-ON POWER, KEEP 2 TIMES SHORT-BEEP 8. FLASHING GREEN, AFTER TURN OFF DIP-SWITCH. 关闭电源,打开 DIP 的[ ON ],再打开电源,电板会发出短促的畔声并闪烁绿灯,关闭DIP-

